

---

# How To Program Universal Remote

---

*How To Program  
Universal Remote*

*Downloaded from  
[db.whlcarchitecture.com](http://db.whlcarchitecture.com)  
by Kennedy & Wiggins*

---

## STREAMLINING YOUR ENTERTAINMENT: THE COMPLETE GUIDE ON HOW TO PROGRAM A UNIVERSAL REMOTE

---

In today's connected home, a cluttered coffee table stacked with three, four, or even five different remote controls is a common but frustrating sight. Each device—your TV, soundbar, streaming box, Blu-ray player, and gaming console—comes with its own clicker, and juggling them can turn a cozy movie night into a tedious chore. The solution? A universal remote. This single device promises to replace all the others, offering one-click control over your entire entertainment system. But the magic only happens after you know precisely **how to program a universal remote**. Whether you have a new GE, RCA, Philips, or Logitech Harmony model, the underlying process is straightforward once you understand the methods. This comprehensive guide walks you through every step, from identifying your remote's capabilities to troubleshooting common hiccups.

---

## UNDERSTANDING YOUR UNIVERSAL REMOTE: THE FOUNDATION

---

Before diving into the programming steps, it's essential to recognize that not all universal remotes are created equal. The method you use will depend largely on your remote's brand, age, and

feature set. Most universal remotes fall into one of three categories:

- **Pre-programmed remotes** (often found in cheap bundles) – they already control a limited set of brands out of the box.
- **Code-search remotes** – they require you to enter a numeric code for your device brand or manually search through a list.
- **Auto-code-search or learning remotes** – they can “learn” commands from your original remote via infrared (IR) signals, or automatically detect the correct code.

Knowing which type you own will help you follow the correct procedure. Most modern universal remotes from GE, RCA, and Philips support both manual code entry and an auto-search function. If you own a high-end remote like a Logitech Harmony, programming is done through a computer or smartphone app, which we will cover separately.

---

## STEP 1: GATHER THE NECESSARY INFORMATION

---

Proper preparation makes the programming process smooth. Before you begin, locate the following:

- **The brand and model numbers** of each device you want to control (TV, soundbar, cable box, etc.).
- **The original remote control** for each device (for learning remotes).
- **The code list** that came with your universal remote. If you lost it, you

can often find the PDF on the manufacturer's website by searching for your remote's model number.

- **Fresh batteries** in the universal remote. Weak batteries can cause programming failures.
- **A clear line of sight** between the universal remote and the device you are programming.

Having these items ready reduces frustration and ensures you can complete the setup in one sitting.

### **METHOD 1: MANUAL CODE ENTRY (THE MOST COMMON METHOD)**

This method works for the vast majority of universal remotes. It relies on a database of pre-configured codes assigned to each brand and device type.

## Step 1: Turn on the device you want to program

Manually power on your TV, DVD player, or other component using its original remote or the power button on the device itself. You need the device to be on during code entry so you can test if the code works.

## Step 2: Put the universal remote into program

## mode

On most remotes, you will need to press and hold the **"Setup"** or **"Code Search"** button until the LED indicator (often a small red light) at the top of the remote turns on or flashes. If your remote does not have a Setup button, you may need to press and hold the **"Device"** button (e.g., "TV" or "CBL") for three to five seconds.

**Pro tip:** Consult your remote's manual for the exact key combination. Common alternatives include pressing and holding both the "TV" and "OK" buttons simultaneously, or pressing "SETUP" once and then "DVD".

## Step 3: Enter the first code from your code list

While the LED is lit (and still on), use the number buttons on the universal remote to enter the first four- or five-digit code listed for your device's brand. For example, if you are programming a Samsung TV, you might enter "0623." The LED will typically turn off after you enter the last digit if the code is accepted, or it might flash twice.

## Step 4: Test the code

Now point the universal remote at your device and press the **Power** button. Does the device turn off? If yes, the code is correct. If nothing happens, the code did not work. Repeat the process: press

and hold the Setup button again, re-enter a different code from the list, and test again. Continue until you find a code that turns the device off.

## Step 5: Lock in the code (optional)

Some remotes automatically save the code the moment it works. Others require you to press the Setup button again to exit programming mode. Check the remote's behavior – if the device turned off, try pressing another button like "Volume Up" or "Channel." If it controls the device, you have successfully programmed that device.

---

### METHOD 2: AUTO CODE SEARCH (WHEN YOU DON'T HAVE THE CODE)

---

If you lost your code list or cannot find a working code manually, most universal remotes offer an automatic search feature. This method cycles through all codes in the remote's memory until it finds one that works with your device. It takes longer but is often the most reliable fallback.

## How to auto search on most GE, RCA, and Philips remotes:

1. Turn on the device you want to control.

2. Press and hold the **"Setup"** or **"Code Search"** button until the LED stays on.
3. Press the device button (e.g., "TV") once. The LED will blink and then stay on.
4. Press and release the **Power** button repeatedly (about once per second) until the device turns off.  
**Important:** You must press and release, not hold the button. Each press sends the next code.
5. When the device turns off, immediately press the device button again to lock in the code. The LED will turn off.
6. Test the remote by pressing Power, Volume, and other functions. If they work, you are done.

**Note:** Some remotes have a dedicated "Code Search" button instead of the Power button. In that case, press "Code Search" repeatedly instead of "Power."

---

### METHOD 3: LEARNING REMOTE - TEACHING THE UNIVERSAL REMOTE

---

Learning remotes are more advanced. They do not rely on a code database; instead, they "learn" the IR signals from your original remotes. This is ideal for obscure brands or for functions that aren't supported by standard codes (like discrete input selection). Here's the general process:

1. Place the original remote and the universal remote facing each other, about 2-4 inches apart. The IR transmitters (usually a little dark window at the top of each remote) should be aligned.
2. Press and hold the **"Setup"** button on the universal remote

until the LED blinks twice.

3. Press the button you want to teach (e.g., “Volume Up” on the universal remote). The LED will flash once or twice.
4. Press and hold the corresponding button on the original remote (e.g., “Volume Up”) until the universal remote’s LED blinks twice to confirm the learning.
5. Repeat for each button you want to clone.
6. Exit programming mode by pressing the “Setup” button again.

Learning remotes are fantastic for custom setups, but they require patience and are best used when code entry fails.

---

### HOW TO PROGRAM A UNIVERSAL REMOTE FOR A SOUNDBAR OR AUDIO SYSTEM

---

Many newer universal remotes can control soundbars and AV receivers. The process is identical to programming a TV, except you select the “**AUX**”, “**AUDIO**”, or “**AMP**” device button instead of “TV.” Look up the code for your soundbar brand (e.g., Samsung, Sony, Vizio) from the code list. If no code works, try the auto-search method with the device in “AUX” mode.

---

### PROGRAMMING WITH A SMARTPHONE APP (LOGITECH HARMONY AND OTHERS)

---

High-end universal remotes like the Logitech Harmony series do not use physical code entry. Instead, you connect the remote to your computer or smartphone via USB or Bluetooth and install the Harmony software. The app guides you through selecting your devices from a massive online database, then syncs the configuration to the

remote. This is the easiest method for multi-device activity-based control (e.g., “Watch a Movie” turns on TV, soundbar, and Blu-ray player).

## Steps for Harmony remotes:

1. Download the Harmony app (or install desktop software).
2. Connect your remote as instructed.
3. Create a new activity or device. Enter your TV brand, model number, or search by brand.
4. The app automatically finds the correct codes and uploads them to the remote.
5. Test the activity – you can even customize button assignments.

---

### TROUBLESHOOTING COMMON PROGRAMMING PROBLEMS

---

Even with clear instructions, you may hit a snag. Here are the most frequent issues and quick fixes:

- **Remote doesn’t respond:** Replace the batteries with fresh ones. Ensure no obstructions between the remote and the device.
- **LED won’t stay on:** You might not be pressing the Setup button long enough, or the remote may be in a different mode. Try resetting the remote (remove batteries for 30 seconds).
- **Device turns off but other buttons don’t work:** The code might be partial. Try entering the next code in the list for that brand.

Some remotes support multiple codes per brand.

- **Auto-search cycles forever:** If the device never turns off, the remote may not support that brand. Verify compatibility on the remote's packaging or website. For older devices, you may need a learning remote.
- **Soundbar volume does not change:** Ensure you selected the correct device button ("AUX" or "AUDIO") and that the code controls volume. Some codes only provide power and input switching. Try a different code or use the learning method.
- **Keep your original remotes in a drawer** – you may need them for future learning remotes or for advanced functions not covered by a basic universal remote.
- **Update your remote's firmware** if it supports online updates. New codes and features are sometimes added.
- **Consider an IR blaster** if your devices are in a cabinet without line-of-sight. Many universal remotes have an IR output port for an external emitter.

---

### TIPS FOR A SEAMLESS UNIVERSAL REMOTE EXPERIENCE

---

Once you have mastered **how to program a universal remote**, use these best practices to keep everything running smoothly:

- **Write down the working codes** for each device and keep the list near your entertainment center. If you ever need to reprogram, you won't have to search again.
- **Use activities or macros** if your remote supports them. For example, create a "Play Games" activity that turns on the TV, switches to the gaming console input, and adjusts audio mode.

---

### CONCLUSION

---

Programming a universal remote is a straightforward skill that eliminates remote clutter and simplifies your home entertainment. Whether you use manual code entry, auto-search, or a learning function, the key is patience and a systematic approach. Start by identifying your remote type, power on the device, enter the correct code, and test thoroughly. If you run into trouble, fall back on the auto-search or learning method. With the steps outlined above, you can confidently take control of your living room – one remote, one code at a time. Now your movie nights, gaming sessions, and binge-watching marathons will be powered by a single, unified device, bringing simplicity back to your entertainment corner.