
Maytag Dishwasher Troubleshooting Guide

*Maytag Dishwasher
Troubleshooting Guide*

*Downloaded from
db.whlcarchitecture.com
by Carlie & Ortiz*

INTRODUCTION: WHEN YOUR MAYTAG DISHWASHER ACTS UP

Your Maytag dishwasher is a workhorse in the kitchen, designed to handle the daily grind of dirty dishes, stubborn food residue, and endless cycles. But like any reliable appliance, even the most durable Maytag models can occasionally throw a curveball. A puddle of water on the floor, a cycle that won't start, or dishes that come out less than sparkling can disrupt your routine and leave you frustrated. Before you consider calling a repair technician or shopping for a replacement, it's worth knowing that many common issues can be resolved with a little know-how and a systematic approach. This comprehensive **Maytag Dishwasher Troubleshooting Guide** is designed to walk you through the most frequent problems, help you decode error messages, and provide practical, step-by-step fixes that you can try yourself. From a dishwasher not draining to a unit that's making unusual noises, we'll cover the essentials to get your appliance back in top form. With a focus on safety, prevention, and clear instructions, this guide will empower you to troubleshoot with confidence and save time and money.

UNDERSTANDING THE BASICS OF

YOUR MAYTAG DISHWASHER

Before diving into specific problems, it's helpful to understand the core components of your dishwasher. The main parts include the control panel (electronic or mechanical), the door latch and switch, the water inlet valve, the wash pump and motor, the drain pump and hose, the heating element, and the spray arms. Knowing where these are located can make troubleshooting much easier. Most Maytag models also feature a filter system that requires periodic cleaning. If you have your owner's manual, keep it handy—it often contains a quick troubleshooting chart. However, this guide will cover the most common scenarios that Maytag owners face, regardless of the specific model.

COMMON MAYTAG DISHWASHER PROBLEMS AND QUICK FIXES

1. The Dishwasher Won't Start

You load the dishwasher, add detergent, close the door, press start... and nothing happens. This is one of the most common complaints. The good news is that the fix is often simple.

- **Check the Door Latch:** The dishwasher won't operate if the

door isn't fully closed and latched. Listen for a click. Over time, the latch or strike can become misaligned. Try pressing the door firmly shut. If the latch feels loose, it may need adjustment or replacement.

- **Test the Control Lock (Child Lock):** Many Maytag models have a control lock feature that disables the buttons. This is often indicated by a lock symbol on the display. Consult your manual to deactivate it (usually by holding a specific button for 3-5 seconds).
- **Check Power Supply:** Ensure the dishwasher is plugged in (or hardwired) and that the circuit breaker hasn't tripped. A tripped GFCI outlet can also be the culprit. Reset it and try again.
- **Inspect the Door Switch:** The door switch tells the control board that the door is closed. If it's faulty, the machine won't start. You can test it with a multimeter for continuity, but if you're not comfortable with that, a visual inspection for damage is a good first step.
- **Check for a Delayed Start:** Make sure you haven't accidentally set a delay start timer. Cancel any existing cycle and reset the dishwasher.

2. Dishes Are Not Getting Clean

Nothing is more disappointing than opening the dishwasher to find dishes still covered in food residue or a cloudy film. This is a multi-factor issue, but here are the top things to check.

- **Clean the Spray Arms:** Food particles and hard water deposits can clog the spray arm holes. Remove the lower and upper spray arms (consult your manual for how to detach them). Rinse them under running water and use a toothpick or small wire to clear any blocked holes.
- **Check the Water Temperature:** Your dishwasher relies on hot water to activate detergent and break down grease. The water entering the dishwasher should be at least 120°F (49°C). Run the kitchen faucet until the water is hot before starting the cycle. If your water heater is set too low, dishes won't clean well.
- **Inspect and Clean the Filter:** Maytag dishwashers have a filter system that catches food scraps. If this filter is clogged, water won't circulate properly. Locate the filter (usually at the bottom of the tub), twist it to remove it, and rinse it thoroughly under hot water. Use a soft brush if needed. Make sure it is securely re-installed.
- **Proper Loading and Detergent:** Overloading prevents water from reaching all surfaces. Ensure that large items don't block the spray arms. Also, use fresh, high-quality detergent and fill the rinse aid dispenser. Hard water requires more detergent or a rinse aid.
- **Check for a Failing Wash Motor or Impeller:** If you hear the dishwasher running but the water isn't moving strongly, the wash pump impeller might be damaged or the motor could be failing. This usually requires professional attention.

3. The Dishwasher is Leaking Water

Finding water on your kitchen floor is alarming. The source of a leak can often be traced to a few common areas.

- **Check the Door Gasket:** The rubber gasket around the door can become brittle, cracked, or have debris stuck to it, preventing a watertight seal. Wipe it down with a damp cloth and inspect for damage. If the gasket is torn or hardened, it needs to be replaced.
- **Inspect the Drain Hose:** The hose that carries water from the dishwasher to the garbage disposal or drain can develop pinhole leaks or become loose at the connection points. Tighten the hose clamps and inspect the hose for cracks.
- **Examine the Water Inlet Valve:** This valve is where the water supply line connects to the dishwasher. If the fitting is loose or the valve itself is leaking, you'll see water at the bottom front of the machine. Tighten the connection or replace the valve if necessary.
- **Look at the Float Assembly:** The float is a small device in the bottom of the tub that prevents overfilling. If it gets stuck in the down position, the dishwasher may overfill and leak. Make sure it moves freely.
- **Check the Drain Pump:** A leaking drain pump can drip water. This is less common but possible.

Look for water pooling directly under the machine.

4. The Dishwasher is Not Draining

Standing water at the bottom of the dishwasher is a clear sign of a drainage problem. Here's how to tackle it.

- **Clean the Filter and Sump:** A clogged filter is the number one cause of draining issues. Remove and clean the filter thoroughly. Also, check the sump area beneath the filter for any large debris that may have fallen through.
- **Check the Drain Hose for Kinks:** If the drain hose is bent or twisted, water can't flow out. Make sure the hose runs in a smooth, upward loop (air gap) before connecting to the disposal or drain.
- **Clear the Garbage Disposal:** If your dishwasher drains into a garbage disposal, run the disposal to clear any clogs. A blocked disposal can prevent the dishwasher from draining.
- **Inspect the Drain Pump:** If the drain pump is faulty, you might hear a humming sound but no water movement. The pump impeller could be jammed with a small object like a piece of glass or a bone. You may need to access the pump and clear the obstruction.

5. Unusual Noises During Operation

A noisy dishwasher can be annoying, but the sound often tells you what's wrong.

- **Grinding or Rumbling:** This usually indicates that a hard object (like a bone, pit, or piece of glass) has fallen into the wash pump or sump. Stop the cycle, drain the water, and check the filter and pump area for foreign objects.
- **Whistling or High-Pitched Sound:** This can be caused by a restricted water supply or a partially closed water valve. Make sure the water supply line is fully open.
- **Slapping or Hitting:** This often happens when a spray arm is hitting dishes or a utensil has fallen through the rack. Check that spray arms rotate freely and that no items are protruding.
- **Clicking:** A single click during a cycle is often normal (relays engaging). However, rapid or constant clicking could indicate a failing main control board or a stuck relay.

DECODING MAYTAG DISHWASHER ERROR CODES

Many newer Maytag dishwashers feature a digital display that shows error codes to help pinpoint issues. Here are some common codes and what they mean.

- **F1 or E1 / Flashing Lights:** This often indicates a water leak or a

moisture sensor issue. Check for leaks under the machine and ensure the unit is level. Sometimes a simple reset will clear it.

- **F2 or E2 / 2 Flashes:** Typically points to a floating switch or overfill condition. The dishwasher thinks it has too much water. Power cycle the unit and check the float assembly for free movement.
- **F3 or E3 / 3 Flashes:** Usually related to a heating element issue. The water may not be heating properly. This could be a faulty heating element or a bad thermistor. If you suspect this, it's best to call a technician.
- **F4 or E4 / 4 Flashes:** Indicates a drain problem. The dishwasher tried to drain for too long. Clean the filter, check the drain hose, and ensure the pump is working.
- **F5 or E5 / 5 Flashes:** Often signals a water temperature sensor issue or a problem with the wash motor. If the machine runs but the dishes are cold and dirty, this could be the culprit.
- **F7 or E7 / 7 Flashes:** Points to a communication error between the control board and the user interface (keypad). This usually requires a board replacement.

Note: To reset most Maytag dishwashers, press the "Start/Resume" button for about 10 seconds or cancel the current cycle. For persistent error codes, refer to your owner's manual for model-specific diagnostics.

STEP-BY-STEP TROUBLESHOOTING FOR SPECIFIC ISSUES

How to Fix a Dishwasher That Won't Drain

1. Start by unplugging the dishwasher or turning off the circuit breaker for safety.
2. Remove the bottom rack and locate the filter assembly. Twist and lift it out.
3. Clean the filter under hot water. Also, feel around inside the sump for any foreign objects.
4. Check the drain hose connection behind the dishwasher (you may need to pull the unit out slightly). Ensure the hose is not kinked and that the clamp is tight.
5. If you have a garbage disposal, run it to clear any blockage.
6. Manually check the drain pump impeller. You can often access it

from the bottom of the dishwasher by removing the lower cover panel. Use a flashlight to look for obstructions. If you see something, carefully remove it with needle-nose pliers.

7. Plug the dishwasher back in and run a rinse cycle to test if it drains.

How to Resolve a Dishwasher Not Cleaning Properly

1. Run the kitchen faucet until the water is hot before starting the dishwasher.
2. Remove both spray arms and clean out the nozzles with a toothpick.
3. Deep clean the filter and the area around the wash pump.