
How To Use A Router

Downloaded from
db.whlcarchitecture.com
How To Use A Router
by Lopez & Rhett

INTRODUCTION: MASTERING YOUR WOODWORKING ROUTER

If you are looking to elevate your woodworking projects from simple to stunning, learning **how to use a router** is one of the most transformative skills you can develop. A router is a versatile and powerful tool that can edge profiles, cut joinery, hollow out areas for inlays, and trim laminates with precision. However, for the beginner, its speed and spinning bits can be intimidating. This comprehensive guide will walk you through everything you need to know, from essential safety protocols to advanced routing techniques, ensuring you can approach this tool with confidence and skill.

Whether you are building furniture, crafting cabinets, or working on smaller hobby projects, mastering the router opens up a world of creative possibilities. We will cover the different types of routers, the bits they use, and the step-by-step methods for common tasks. Let us begin your journey to becoming a proficient router user.

UNDERSTANDING THE ROUTER: TYPES AND ANATOMY

Before you can effectively use a router, you need to understand the tool itself. There are two primary types of routers, each suited for different tasks. Knowing the differences will help you choose the right tool for your project and master

how to use a router effectively.

Fixed Base vs. Plunge Base Routers

Fixed Base Router: This is the most common type. The motor is housed in a base that does not move up and down. You set the depth of cut, lock it in place, and the bit stays at that depth throughout the operation. Fixed base routers are excellent for edge work, such as rounding over corners or cutting decorative profiles. They are generally lighter and easier to handle for routing the edges of a workpiece.

Plunge Base Router: A plunge router has a spring-loaded base that allows you to lower the spinning bit into the workpiece vertically. This is ideal for tasks like cutting mortises, creating grooves in the middle of a board, or making through cuts. The ability to plunge into the material gives you greater control when starting a cut away from the edge. Many routers come as a **router combo kit**, offering both bases that share the same motor, giving you maximum flexibility.

Key Parts of a

Router

Regardless of the type, every router has several crucial components you must be familiar with:

- **Motor:** The heart of the tool, typically ranging from 1 to 3 horsepower.
- **Collet and Collet Nut:** These hold the router bit in place. The collet tightens around the bit's shank when you tighten the collet nut. Common collet sizes are 1/4 inch and 1/2 inch.
- **Base:** The flat plate that rides along the surface of your workpiece. A stable, smooth base is essential for accurate routing.
- **Depth Adjustment Ring or Knob:** Used to set the cutting depth of the bit. Precision here is key for successful routing.
- **Switch:** The on/off control. Always ensure your router has a safety lock to prevent accidental startups.

ESSENTIAL ROUTER SAFETY: YOUR FIRST PRIORITY

Using a router involves high-speed spinning cutters, so safety is non-negotiable. Before you even plug in the tool, internalize these safety rules. A safe woodworker is a successful woodworker, and understanding the risks is a critical part of learning how to use a router.

1. **Always Wear Personal Protective Equipment (PPE):** This includes safety glasses or a face shield to protect against flying debris and ear protection to guard against the high-pitched

whine of the router. A dust mask is also highly recommended.

2. **Secure Your Workpiece:** Never hold a workpiece with your hands alone. Use clamps to secure the wood firmly to your workbench or router table. The router's rotation can easily pull the workpiece away from you.
3. **Mind the Direction of Cut:** This is a fundamental rule. You should generally move the router from left to right along a workpiece edge, moving against the rotation of the bit. This is called **conventional cutting**. Moving with the rotation (climb cutting) can cause the router to grab and run, which is dangerous for beginners.
4. **Unplug the Router for Bit Changes:** Never, ever change a bit while the router is plugged in. A bump of the switch can have catastrophic consequences. Make it a habit to unplug before any adjustment.
5. **Use Sharp Bits:** Dull bits require more force to push, increase the risk of burning the wood, and are more likely to cause kickback. Always start with a sharp bit.
6. **Check the Collet Tightness:** Ensure the bit is fully inserted into the collet (at least to the depth of the collet flutes) and that the collet nut is tightened securely. A loose bit can be thrown at high speed.

STEP-BY-STEP GUIDE: HOW TO USE A ROUTER FOR EDGE PROFILING

Edge profiling is the most common task for beginners and a perfect

way to learn how to use a router. Here is a step-by-step guide to creating a decorative edge on a board.

Step 1: Gather Your Tools and Materials

You will need your router, a suitable bit (like a round-over or chamfer bit), a workpiece, clamps, and your safety gear. Choose a bit with a **pilot bearing** for this task, as the bearing will guide the bit along the edge of the wood.

Step 2: Install the Router Bit

Unplug your router. Loosen the collet nut, insert the bit's shank, and tighten the nut securely using the included wrenches. Ensure the bit is not touching the bottom of the collet.

Step 3: Set the Cutting Depth

For a round-over bit, you typically want the bearing to ride along the edge of the wood. Adjust the depth so the bearing is level with the wood's edge and the cutting portion is exposed. For a fixed base router, loosen the base lock, adjust the motor up or down, and lock it.

Step 4: Secure the Workpiece

Clamp your workpiece firmly to your bench. Make sure the edge you are routing is clear of the clamps and accessible. The wood must not move during routing.

Step 5: Make the Cut

Put on your safety gear. Plug in the router, hold it firmly with both hands, and turn it on. Allow the motor to reach full speed. Slowly bring the router bit into contact with the edge of the wood. Move the router from **left to right** along the edge, applying gentle, consistent pressure. Let the bit do the cutting; do not force it. Go with the grain where possible to reduce tear-out.

Step 6: Finish and Inspect

Once you have completed the pass, move the router away from the workpiece and turn it off. Wait for the bit to stop spinning completely before setting the router down. Inspect your edge. If you need a deeper cut, adjust the bit depth and make another pass.

UNDERSTANDING ROUTER BITS: YOUR SHAPE LIBRARY

To truly master how to use a

router, you must understand the bits. Each bit creates a different profile or function. The quality of your bit directly impacts the quality of your cut.

Common Bit Types

- **Straight Bit:** Used for cutting grooves, dados, and mortises. It cuts straight down into the wood.
- **Flush Trim Bit:** Has a bearing on top that rides on a pattern or template, allowing you to trim one material flush with another.
- **Round-Over Bit:** Creates a rounded edge, softening the sharp corners of a board.
- **Chamfer Bit:** Cuts a beveled edge, typically at a 45-degree angle.
- **Rabbeting Bit:** Cuts a step or rabbet along the edge of a board, often used in joinery for shelves and drawers.
- **Dovetail Bit:** Used to create dovetail joints, a hallmark of fine woodworking. Often used with a dovetail jig.

Bit Shank Size and Material

Bits come with 1/4-inch or 1/2-inch shanks. A 1/2-inch shank is stiffer and less prone to vibration, resulting in a cleaner cut, especially with larger bits. Always use carbide-tipped bits for

durability and longevity, as they stay sharp far longer than high-speed steel (HSS) bits.

ADVANCED TECHNIQUES: ROUTING DADOES AND GROOVES

Once you are comfortable with edge work, you can use a router to cut joinery like dados and grooves without a table saw. This is a key skill in learning how to use a router for furniture making.

Using a Straight Edge Guide

To cut a groove in the middle of a board, you need a guide to keep your router moving straight. You can purchase an **edge guide** that attaches to your router's base, or you can clamp a straight piece of wood (a straightedge) to your workpiece to act as a fence.

Steps to cut a dado:

1. Mark the location of your dado on the workpiece.
2. Clamp a straightedge to the workpiece, offset by the distance from the router's base edge to the center of the bit.
3. Set your bit depth to the desired depth of the dado.
4. Start the router, let it reach speed, and make the cut, keeping the router base firmly against the straightedge.
5. For wider dados, make

multiple passes, moving the straightedge slightly for each pass.

USING A ROUTER TABLE: EXPANDING YOUR CAPABILITIES

A **router table** is a game-changer. It turns your handheld router into a stationary tool, offering improved control and precision for certain tasks. Mounting your router upside down in a table allows you to feed the workpiece into the bit, similar to using a shaper.

Benefits of a Router Table

- **Greater Control:** You use both hands to guide the workpiece, which is safer and more precise for small or complex pieces.
- **Consistent Results:** Using the table's fence ensures perfectly straight cuts for rabbets and grooves.
- **Easier for Small Pieces:** Routing small parts by hand is dangerous. A router table allows you to push the piece safely with push sticks.
- **Better for Large Profiles:** Large bits, like raised panel bits, are much safer to use in a router table.

Key Safety

Tips for a Router Table

Always use a **starter pin** when routing curved work and feather boards to hold the workpiece against the fence. Never remove the safety guards. Always feed the workpiece against the rotation of the bit (from right to left, towards you). Learning how to use a router in a table configuration is a natural progression for any serious woodworker.

TROUBLESHOOTING COMMON ROUTER PROBLEMS

Even with good technique, you will encounter issues. Here is how to solve common problems:

- **Burned Wood:** You are moving too slowly, the bit is dull, or you are trying to remove too much material in one pass. Speed up your feed rate, use a sharper bit, or take multiple shallow passes.
- **Tear-Out:** Splintering at the end of a cut is often caused by routing against the grain or exiting a cut poorly. Climb cut (carefully) for the final light pass, use a sacrificial piece of wood on the exit side, or route the ends of a board first.
- **Chatter or Vibration:** This usually indicates a loose bit, an unbalanced bit, or taking too deep a cut. Check your collet tightness and use a bit

with a 1/2-inch shank for better stability.

- **Router Runs Away:** This is often due to climb cutting (moving with the bit's rotation) too aggressively. Always use conventional cutting as a beginner, and keep a firm grip on the

router.

ROUTER MAINTENANCE FOR LONGEVITY

Proper maintenance will keep your router performing well for years. Learning how to use a router also means learning how to